

TR200 DRIVE STANDARD FEATURES**The TR200 Trane Drive**

The TR200 Drive Series is a microprocessor-based, high frequency IGBT-based, PWM AC drive with control functions and software designed solely for the unique needs of HVAC systems. The TR200 Drive uses state-of-the-art Voltage Vector Control to supply full rated motor voltage at rated load and frequency, full motor performance without derating, high efficiency for both drive and motor, and a nearly perfect output sine wave. The diode-bridge rectifier and DC-link reactor provide a high displacement power factor at all speeds and loads and minimize power line harmonics. The TR200 Drive utilizes a common user interface for all units.

Input Line Conditioning

A dual, 5% DC-link reactor on the positive and negative rails of the DC bus is standard equipment on the TR200 Drive. This reactor reduces the level of harmonics reflected back into the building power system without causing a voltage loss at the drive's input and reducing efficiency as an external AC line reactor would. This reactor also improves input power factor. The reactor is non-saturating (linear) to provide full harmonic filtering throughout the entire load range. In performance, the DC-link reactor is equivalent to a 5% AC line reactor.

Input EMI and RFI Filtering

All TR200 Drives are designed to contain and control EMI and RFI to stringent European standard EN 61800-3. The Class A rating for the FCC rule that is commonly specified for drives has to do with commercial and industrial environments. Our Standard Class A2 filter is related to industrial environments.

Slip Compensation

The TR200 compensates for the motor slip by giving the frequency a supplement that follows the measured motor load keeping the motor speed almost constant.

Output Carrier Frequency

By using IGBTs, the TR200 Drive can employ high switching frequencies, so the motor current is practically sinusoidal. Audible motor noise can also be minimized by adjusting the switching frequency. These frequencies can be set or adjust themselves automatically to fit the application.

Galvanic Isolation of Control Terminals

All control terminals and output relay terminals are galvanically isolated from the power line. This means the drive controller is completely protected from the input current. The output relay terminals require their own grounding. This isolation meets the stringent protective extra-low voltage (PELV) requirements for isolation and ensures safe connection to building management systems.

Adjustable Acceleration / Deceleration Rates

The TR200 Drive can provide four individually controlled sets of acceleration/deceleration rates each from 1 to 3600 seconds. The shape of these curves may be automatically contoured to prevent tripping. The TR200 shall also provide an S-Curve shaped acceleration/deceleration ramp.

SELF-PROTECTION AND RELIABILITY FEATURES**Input Power Line Protection**

Power line voltage surge protection is provided by means of input Metal Oxide Varistors (MOVs). This protects the diodes in the TR200 Drive's 3-phase full wave diode bridge. The DC-link reactor also acts to reduce input current caused by power line disturbances.

Loss of Input Signal Protection

Upon a loss of a control signal the TR200 Drive provides multiple options to select for the proper protection. The drive can be sent to a default speed, use the recent value, stop and/or send an alarm.

Loss of Power or Phase Protection

The TR200 Drive is equipped with an automatic sustained power or phase loss circuit. The TR200 Drive will provide a full rated output with an input voltage as low as 90% of the nominal. The drive will continue to operate with reduced output with an input voltage as low as 164 volts for 208/230 volt units, 313 volts for 460 volt units, and 394 volts for 600 volt units.

Overcurrent Protection

Adjustable from 0 to 110% of the TR200 Drive's rated current (factory set at 110%). If during acceleration the current required to accelerate the load exceeds the current limit, the TR200 Drive will stop accelerating until the motor current is reduced to normal levels, at which time the load will continue to accelerate at the rate set by the acceleration time.

Advanced Motor Protection

The TR200 Drive features integrated electronic, thermal motor protection. The VFD calculates the motor temperature based on current, frequency, and time. This system allows for changing cooling conditions as speed and load vary. The drive can predict motor overheating and reports a % of thermal load.

Automatic High Ambient Derate

If the ambient temperature exceeds the normal limit, the drive can be set to warn of its overtemperature and continue to run, keeping the HVAC system functional. To control its temperature, the drive will reduce the output carrier frequency and then, if necessary, reduce the output current.

Automated Frequency Avoidance and Lockouts

For applications where it may be necessary to avoid specific frequencies due to mechanical resonance problems in the driven equipment, the TR200 Drive, with its Critical Frequency Lockout Function, makes it possible to set up to four different frequency ranges which will be avoided during operation of the drive. This feature can be programmed by simply activating the feature and pushing OK at the top and bottom points that you wish to avoid.

Each critical frequency setting can avoid a frequency band which is from 1 to 100 Hz wide. If the reference signal defines that the TR200 Drive is to operate within this critical frequency range, the critical frequency lockout function will keep the drive operating continuously within this range.

When the frequency reference signal rises above the critical frequency maximum limit, the TR200 Drive will allow the motor to accelerate through the critical frequency at the rate set by the acceleration rate.

Instantaneous line-to-line and line-to-ground overcurrent trips

TR200 monitors if there is a discharge from the output phases to ground, either in the cable between the adjustable frequency drive and the motor or in the motor itself.

Short Circuit Protection: The TR200 Drive provides inherent short circuit protection with a very fast acting fault trip circuit by sensing current on all three drive output phases. The use of insulated gate bipolar transistors (IGBT) in the TR200 Drive means very high-speed switching and rugged performance.

Automatic Restarts: The TR200 Drive can be automatically restarted up to 20 times or infinitely at 0 to 600 second intervals. If the application causes the drive to trip more than the number of trials set, the drive will stop operating and display the fault on the display screen. A manual reset will be required by means of the reset key, a digital input, or EIA-485 command. In cases of severe trips, as a safety feature, the drive's input power may have to be cycled to restart a fault.

Bidirectional Autospeed Search

Allows starting into a "windmilling" fan at any speed, in either direction. This function makes it possible to catch a motor which is spinning freely due to a mains drop-out.

Torque Boost

The TR200 Drive's constant-torque start mode provides full torque to accelerate different loads until the drive reaches the setpoint. Breakaway current can be set up to 160% for up to 0.5 seconds for starting high friction loads.

Stall Protection

The TR200 Drive provides protection against a stalled motor. When activated, this function can provide a warning or a fault condition caused by excessive motor current at low speeds.

Three-Phase Output Current Measurement

The TR200 Drive's software measures output current on all three phases. Phase grounding is detected instantly. Output contactors may be repeatedly used with no damage to the drive. Multiple motors may be run from one drive.

Automatic Energy Optimization Circuitry

The Automatic Energy Optimization (AEO) function adapts the output of the drive to the specific motor and load connected. This circuit optimizes the system efficiency as system loads change. The AEO function regulates the output voltage on the basis of the reactive current and the effective current. A savings of 3 to 10% in power consumption can be obtained with this function.

Automatic Motor Adaptation (AMA)

Knowing motor stator resistance, the drive automatically optimizes performance and efficiency. The motor does not have to be run or decoupled from the load for the AMA setup to be performed.

Broken Belt, Loss of Load

A minimum motor current value can be set to indicate the motor is not using any more current than to run at idle. This can be used to indicate a broken belt or coupler. This feature can also be used to detect when a motor is disconnected from the drive.

Energy Monitoring

Real energy savings are always available without the additional expense of external equipment.

Preset Speeds

The TR200 Drive allows for a maximum of 16 programmable preset speeds to be selected from the digital inputs.

Preventive Maintenance Scheduling

The TR200 Drive can monitor system usage and notify the operator when preventive maintenance is required.

TR200 DRIVE – CONTROLS AND INDICATIONS

Panel-mounted Operator Station

The TR200 Drive uses a large, bright, backlit graphic display to provide complete drive information at a glance. The logical arrangement of all elements simplifies the setup, operation and monitoring of the drive. Choose from 25 different items to display, including input reference, motor current, hours run, output frequency, horsepower, kW or kWh. Or select from custom units, such as GPM or HP and calibrate the maximum value to the maximum frequency of the unit. After programming one drive, the keypad can be used to transfer the same settings to all other drives. Drive can run without the keypad in place to assure tamper-proof operation. Drive status is shown even with the keypad removed.

Application-Specific Software

The TR200 Drive was designed specifically for the HVAC market. This specialization has allowed TRANE to factory program and configure the TR200 Drive to make it ready to use, out of the box. For the advanced user, the parameters are logically grouped, making modifications simple. Customized text fields are available to show user-specific data. Four independent setups are available for unmatched flexibility.

Status Lights

Three LEDs are provided on the TR200 Drive for indication of power applied, warning and fault. Upon power up, all LEDs will briefly light as a lamp test.

- Alarm – Will flash red when the drive has registered a fault condition which has caused the drive to shut down.
- Warning – Will flash yellow to indicate a situation exists that exceeds the normal drive/system parameters, and if that condition continues, a trip may be imminent.
- On – Will glow green to indicate that the VFD is connected to AC power (line voltage is present) In addition to the status lights, up to five separate meters can be displayed simultaneously Operating Keys for four conditions of control authority:
- Off – Stops the motor, regardless of other commands.
- Hand On – Starts the VFD in Local control. An external Stop signal overrides the local Hand On.
- Auto/On – The drive will start and stop via a remote signal (BAS or time clock).
- Reset – Will reset any trip level fault (not trip lock) if the drive is not set for infinite automatic fault resets.

Menu Structure

- Quick Setup Menu – Contains the 14 required setup parameters to easily start the application.
- HVAC Application Menu – Easy access to the relevant parameters for each of the most common applications.
- Personal Menu – Contains up to 20 user-selectable parameters for customized access.
- Changes Made Menu – Provides easy access to previously modified parameters Directional keys
- Right / Left / Up / Down arrows – Used as the electronic potentiometer to manually control the speed in the Hand/Start mode. All four keys are active during operation as well as programming. They provide the ability to move the cursor around the display, or sequence through display values.

Programming Keys

- Status – Used to display operational data and status.
- Cancel – Used to cancel the last programming command so the change is not carried out.
- OK – Used to confirm that the last programming change should be saved to memory.
- Back – Used to exit present display or menu to the previous display or menu.
- Quick Menu – Used for programming the TR200 Drive for the most typical applications.
- Main Menu – Used to access all parameters for programming; it can switch directly from this to quick menu
- Alarm Menu – Used to access all fault and warning data.
- Info Key – Accesses an on-board manual that gives detailed explanation of a parameter.

Additional Keypad Features

- Hot-pluggable with upload and download capabilities, On-screen scroll bars and graphs
- Three-level password protection: No Access, Read-only and Full Access
- Plain language alarms and warnings
- Remote keypad mounting kits available

Control Signal Interfaces

- Two Programmable Analog inputs: scalable 0 to 10 VDC or 0/4 to 20mA
- Six Programmable Multi-functional Digital Inputs
- One Programmable Analog output: 0/4 to 20mA
- 2 Programmable Relay outputs: 240 VAC, 2 amp
- PID Control Interface: four auto-tuning PIDs control the drive and up to three other devices, eliminating external controllers and reducing cost

TR200 DRIVE - CUSTOM APPLICATIONS

Run Permissive Circuit

Ability to accept a "system ready" signal assures that dampers or other auxiliary equipment are in the proper state for drive operation. This feature also provides the ability for the drive to send a "start signal applied" signal to the system to notify the auxiliary equipment of the drive's request to start.

Sleep Function

Automatically stops the drive when speed drops below set "sleep" level for specified time. Automatically restarts when speed command exceeds set "wake" level. Saves energy and reduces wear on driven equipment.

Motor Preheat Function

This preheat function can be activated to avoid condensation on the motor windings when it is stopped.

Firefighter's Override Mode

Overrides all other commands to provide desired operation. Ignores most alarms including overload, overcurrent, over temperature, and phase loss. When used with bypass, selectable to run from drive, from bypass, or switch from drive to bypass in the event of a drive failure. Fire Mode is clearly indicated on the TR200 display to prevent any confusion.

BAS Interface

The TR200 Drive is fully equipped for serial communication (EIA-485). Up to 31 drives can be connected to one serial bus up to 5,000 feet long. The TR200 communicates directly with, BACnet MS/TP, Johnson Controls Metasys (N2), Siemens Building Technologies System 600 (FLN), and Modbus RTU systems with no hardware changes or additional costs. **Optional communications:** include an Advanced *BACnet MS/TP* and *LonWorks* by adding an Option A card.

USB Connectivity

The TR200 Drive can be remotely commissioned and monitored through a standard USB connection and Trane Drive Utility PC software.

TR200 DRIVE - ENCLOSURES

TR200 enclosures comply with NEMA 250 and include UL labeling.

Plenum Rated

The TR200 NEMA 1 and NEMA 12 drive enclosures are recognized by UL for installation in air handling compartments.

TR200 SPECIFICATIONS

Drive Input Power

Input voltage, 3 phase	200–240, or 380–460, or 525–600 VAC
Input voltage range for full output	Nominal $\pm 10\%$
Undervoltage trip point	164, 313 VAC, or 394 VAC
Overvoltage trip point.....	299, 538, or 690 (792 for 100 HP and above) VAC
Input frequency	60 Hz, ± 2 Hz
Displacement power factor	0.98 or greater at all speeds and loads
Total power factor	0.90 or greater at full load and nominal motor speed

Drive Output Power

Output frequency	Selectable 0 to 120 Hz
Motor voltages	200, 208, 220, 230; 380, 400, 415, 440, 460; 550 or 575 VAC
Continuous output current	100% rated current
Output current limit setting.....	Adjustable to 110% of drive rating
Current limit timer	0 to 60 seconds or infinite
Adjustable maximum speed	From minimum speed setting to 120 Hz
Adjustable minimum speed	From maximum speed setting to 0 Hz
Acceleration time	To 3,600 seconds to base speed
Deceleration time.....	To 3,600 seconds from base speed
Breakaway torque time.....	0.0 to 0.5 seconds (1.6 times motor nameplate current)
Start voltage.....	0 to 10%
DC braking time	0 to 60 seconds
DC braking start.....	0 to maximum frequency
DC braking current.....	0 to 50% of rated motor current

Environmental limits:

Efficiency	97% or greater at full load and nominal motor speed
Ambient operating temperature	14°F to 113°F (frames A2–C2); 14°F to 104°F (frames D1–E1)
Humidity	< 95%, non-condensing
Altitude: maximum without derating.....	3,300 ft.
Drive and options enclosure(s).....	NEMA/UL Types 1 and 12; 3R optional

Software

Lost speed reference action.....	Selectable to go to a preset speed, go to maximum speed, stay at last speed, stop, turn off, or stop and trip
Time delay for lost speed reference action	1 to 99 seconds
Adjustable auto restart time delay	0 to 600 seconds
Automatic restart attempts.....	0 to 20 or infinite
Automatic restart time delay	0 to 600 seconds between each attempt
Relay ON delay and relay OFF delay	0 to 600 seconds
Maximum number of preset speeds	16
Maximum number of frequency stepovers	4
Maximum stepover width.....	100 Hz
Maximum number of accel rates	4
Maximum number of decel rates	4
Delayed Start	0 to 120 seconds
Protections:	
Low frequency and high frequency warnings	0 to 120 Hz
Low current and high current warnings	0 to maximum current
Low reference and high reference warnings	–999,999 to 999,999
Low feedback and high feedback warnings	–999,999 to 999,999
Ground fault	Protected
Motor stall	Protected
Motor overtemperature	Protected (Predictive motor temperature)
Motor Condensation	Protected (Motor preheat circuit)
Motor overload.....	Protected (Programmable action)
The unit is suitable for use on a circuit capable of delivering not more than 100,000 RMS symmetrical Amperes, 480/600 V maximum.	
Vibration protection	Protected (Programming automated)

Control Connections

Follower signal, analog input.....2; selectable voltage or current, direct and inverse acting
Programmable digital inputs 6 (2 can be used as digital outputs)
Programmable analog outputs 1; 0/4 to 20 mA
Programmable relay outputs2 standard Form C 240 V AC, 2 A; 1 or 3 additional optional
Auxiliary voltage..... +24 V DC, maximum 200 mA

Agency Listings

All drives and option packages are factory built and carry UL and C-UL listings.
All drives and option packages are built in ISO 9000 and 14001 certified facilities.
Electrical components and devices are listed and labeled as defined in NFPA 70, Article 100.
All drives comply with NFPA 70.

