WIRE COLOR SCHEME BLACK - LINE VOLTAGE RED - AC CONTROL WHITE - AC GROUNDED
CIRCUIT CONDUCTOR
BLUE - DC CONTROL
GREEN - CHASSIS GROUND EARTH GROUND EARTH GROUND * AC MOTOR (SEE NOTES 6) *CUSTOMER SUPPLIED 1T1 (L1) X T1 L1 (L1) (T1) 1L1 BLK (F15AI) 2L1 5L1 L1/R/91 3<u>T1 (L1)</u> (T1) INPLIT T1/U/96 IF18AII IF16AI [F16B] 5L2 POWER ADJUSTABLE FREQUENCY L2 (L2) (T2) 1L2 BLK 3T2 (L2) (T2) ` 1T2 (L2) T2 FEEDER T2/V/97 ||F188||-3 PH, 208V, L2/S/92 DRIVE | L2/3/92 | SL3 | L3/T/93 CIRCUIT L3 (L3) (T3) 1L3 BLK [[F15C]] 2L3 1T3 (L3) 3T3 (L3) (T3) _2T3 PROTECTION T3/W/98 -IIF18CII-(AFD) (SEE NOTE 3) DRIVE INPUT FUSES MAIN DISCONNECT *AC MOTOR 2 FUSES (SEE NOTES 6) M3 (L1) | (T1) (L2) | (T2) OL2 F19Al AT2 (L2) 12 |F19B| (T3) AT3 (L3) -IF19CII-23 F12 163 RED 101 WHT 115VAC 115VAC 250V TO SHEET 2 TO SHEET 2 HEATER (1) 4 (4) FAN 1 (9) (5) TS1

- 1. * INDICATES COMPONENTS NOT SUPPLIED BY MANUFACTURER.
- 2. REFER TO THE INSTALLATION AND OPERATION MANUAL FOR DRIVE FUNCTIONS AND PARAMETER SETTINGS. 3. FEEDER CIRCUIT PROTECTION, INPUT POWER AND MOTOR WRING MUST BE SELECTED IN ACCORDANCE WITH THE N.E.C., ANY APPLICATION LOCAL CODES AND THE LOAD CURRENT RATING.
- 4. REPLACE JUMPER 'JI' WITH NORMALLY CLOSED SAFETY INTERLOCK CONTACT AS NECESSARY. CONTACT MUST BE RATED 1/4 HP @ 120VAC MINIMUM.
- 5. PANEL MAY REQUIRE DERATING, CONSULT DRIVE MANUAL OR FACTORY FOR FOLLOWING CONDITIONS: 5.1. HIGHER SWITCHING FREQUENCY THEN DRIVE DEFAULT
- HIGHER THEN PANEL LISTED AMBIENT TEMPERATURES
- 5.3. ELEVATION ABOVE 3300 FEET (1000 METERS)
- 5.4. LONG MOTOR LEAD LENGTHS
- 6. WHEN MOTOR OVERLOADS SIZES ARE DIFFERENT, MOTOR 1 WILL BE THE LARGER OF THE TWO MOTORS

WARNING!

THE FOLLOWING TABLE LIST THE PARAMETERS THAT ARE SET DIFFERENT FROM THE DRIVE DEFAULT SETTINGS. ADDITIONAL PARAMETER SETTINGS MAY BE REQUIRED FOR YOUR APPLICATION.

DRIVE PARAMETER SETTINGS

PARAMETER #	NAME	SETTING	VALUE			
0-02	MOTOR SPEED UNIT	1	HZ			
0-03	REGIONAL SETTINGS	1	NORTH AMERICA			
1-03	TORQUE CHAR.	1	VARIABLE TORQUE			
5-02	TERMINAL 29 TYPE	1	OUTPUT			
5-11	TERMINAL 19	52	RUN PERMISSIVE			
5-31	TERMINAL 29	5	RUNNING			
5-40[0]	RELAY 1	160	NO ALARM			
5-40[1]	RELAY 2	167	START COMMAND			
14-20	RESET MODE	13	INFINITE AUTO REST			

B A	ECNSP09001	1/09	-NOTICE- THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN CONSENT OF THE TRANE COMPANY	DRN DTM	DTM ,MAIN DISC,MAIN & DRIVE FUSE					THE TRANE COMPANY A DIVISION OF AMERICAN STANDARD INC.
REV	ECN ECN	DATE		DTM	MODEL	VLT	PAGE <u>1</u> OF <u>2</u>	SIZE	DWG 17	4N4433

